

## Natralis<sup>™</sup> and Medintone<sup>™</sup> with Diamond 10° Technology Heat Welding Installation Tips

Natralis" and Medintone" homogeneous sheet with Diamond 10° Technology requires no additional tools or techniques. Below are a few tips for heat welding seams.

- Natralis and Medintone with Diamond 10 Technology patterned and solid weld rods are full round rods and use 4 mm round nozzles.
- Solid weld rods are available in 164 ft. (50 m) per spool.
- Set temperature to 650°- 850°F (340° 450°C) and allow welding gun to pre-heat for several minutes.
- For additional protection, after the final skive, wipe the welded seam with a clean, damp cloth. When dry, apply a thin, even application of a commercially available, high-quality multi-purpose top coating such as Armstrong S-762 Weld Rod Coating Pen. In high traffic areas, apply one or two additional coats, making sure the finish is completely dry between applications.

**NOTE:** Use care when applying the finish to avoid over application onto the wear layer of the adjacent sheet flooring material.

## **Armstrong**Flooring