

MAINTENANCE INSTRUCTIONS

Armstrong Flooring – Audacity® Luxury Vinyl Plank
Armstrong Flooring – Audacity® Hybrid Rigid Core

Initial Care

After installation is completed, the following must be performed:

1. Remove all debris with an electrostatic, Micro fibre mop or vacuum
2. Use a damp mop to clean with Armstrong Flooring Once n' Done (or similar pH 7.0-8.5 neutral cleaner).

Regular Maintenance

- Sweep, Micro fibre mop or vacuum your new floor regularly to remove loose dirt which can scratch your floor.
- The use of residential steam mops on this product is acceptable. Use at lowest power with a suitable soft pad, and do not hold a steam mop on one spot for an extended period of time (longer than 1 minute). Refer to the steam mop's manufacturer instructions for proper usage.
- Wipe up spills as soon as possible.
- Damp mop your floor regularly with a neutral detergent such as Armstrong Flooring Once 'n' Done floor cleaner (or similar pH 7.0-8.5 neutral cleaner).
- Do NOT use detergents, abrasive cleaners, or "mop and shine" products. These products may leave a dull film on your floor.
- Do NOT use wax or solvent based polishes.
- Do not use highly alkaline 'floor strippers' to clean the floor covering. Highly alkaline solutions have the potential to damage the adhesive bond between the planks and substrate.
- Never use highly abrasive scrubbing tools on any resilient floor.

Proactive protection of your floor

- Use proper floor protectors (such as felt pads) under furniture to reduce indentation. As a general rule of thumb, the heavier the item, the wider the floor protector needed.



- Place a walk-off mat at outside entrances to reduce the amount of dirt brought into your home. Armstrong Flooring strongly recommends the use of mats without a latex or rubber (particularly black) backing as these can cause permanent discoloration.
- Do not drag or slide heavy objects across the floor. When moving appliances or heavy furniture it is always wise to lay a plywood sheet, or similar, on your floor and "walk" the item across it. This protects your floor from scuffing, gouging and tears.

Armstrong Flooring Pty Ltd
29 - 39 Mills Road, Braeside, 3195 Victoria Australia
For further information and samples:
Australia Freecall 1800 632 624
Email customer_services@armstrongflooring.com or contact us on the web
www.armstrongflooring.com.au/residential

February 2019 V4.

FLOORING < > TRA

