



SLIP RETARDANT SHEET MAINTENANCE TIPS


Initial Care:

1. Remove all debris from the floor


Allow 48 hours before carrying out the following:

2. Damp mop / scrub using a neutral cleaner (Armstrong ONCE 'N DONE). [If floor is badly soiled then strip back using a low alkali stripper (Armstrong NEW BEGINNING) and rinse well].
3. Rinse floor thoroughly with clean water

Ongoing Care:




Sweep / Vacuum **DAILY**




Damp Mop
(Nylon/Rayon)
REGULAR

OR



Scrub
(Using Scrub Brushes Only)
REGULAR



Heavy Duty Scrub
AS REQUIRED

Routine Maintenance:

Sweep regularly and mop regularly using a neutral detergent (Armstrong ONCE N' DONE). Frequency and type of function depends on traffic flow, environmental conditions, access and customer requirements. Frequency may need to be adjusted depending on the prior conditions, especially if a light colour has been chosen.

Prevention:

Ensure adequate protective matting is used at entrances, more dirt stopped at the entrances means less dirt trafficked through the building. Sand and grit are abrasive and damage floors. Ensure adequate protection is afforded under furniture.

General Hints:

1. **DO NOT USE** floor maintenance pads on this product.
2. Finish systems should not be applied to Slip Retardant Sheet as they fill the textured areas and cause a reduction in slip retardance.
3. If heavy duty cleaning is required, use extra strength cleaners and a stiffer scrub brush.
4. **DO NOT USE** benzine, toluol, acetone, trichloroethene, thinner, oilwax or strong scouring powders as these will damage the floor.
5. Auto scrubbing in unobstructed areas takes approximately 20% of the time of damp mopping. For maximum efficiency use damp mopping in obstructed areas only.
6. Spot mopping / spot scrubbing should be used when necessary. **Spillages** – post wet floor signs and wipe up immediately. Allow to dry and remove signs.
7. All resilient flooring should be protected during the construction period (use Armstrong TOPGARD).

For further Armstrong information:
Freecall 1800 632 624

